

HINDS-BOCK AUTOMATIC BUCKET & TUB FILLING AND LIDDING

Automatically denests buckets & tubs. Automatic filling with a bottom-up feature for stiff products (optional). A positive two-stage/clamp system is used to ensure proper placement of lid as it leaves the lid denester. Progressive roll down lidding mechanism is utilized to apply lids securely. A gentle piston transfer pump can be added to automatically load hopper.

Speeds of 10 containers a minute or more are achievable.



 **HINDS-BOCK**
CORPORATION

14690 N.E. 95th ST. REDMOND, WA 98052-2544 USA
877.292.5715 Toll Free • Tel: 425.885.1183 • Fax: 425.885.1492
E-mail: info@hinds-bock.com Website: hinds-bock.com